

WOODY PET



WOODY PET HORSE & FARM STALL BEDDING is the ideal product to use with **THE GREEN MACHINE!**

Let's face it, nothing gets better than sifting the **WORLDS MOST AMAZING HORSE BEDDING** with **THE WORLDS MOST AMAZING BEDDING SIFTER.**

THE GREEN MACHINE works well with all bedding materials as long as they are small enough to pass through the screen which is a 1/2 inch by 1 inch diamond grid. Wood shavings are fine as long as they are the common smaller type and not too large.




WOODY PET PRODUCTS INC.
Email: sales@woodypet.com
Website: www.woodypet.com
TOLL FREE: 1-888-535-9816

Made in Canada

WOODY PET

INTRODUCES

THE Green Machine™



Steel Constructed, Electrically Operated SIFTING MACHINE

Automatically removes the manure from the bedding, both cleaning and mixing the bedding in one smooth operation.

THE Green Machine™

Takes the BROWN out of your bedding!
Puts more \$-GREEN into your pockets!
Gives you more time on your hands!



Cleaning Stalls with a Sifting Machine went through a two year evaluation test with JOHN LYONS at his ranch in Colorado. Perfect Horse Magazine published a review in the December 1999 issue: "...we tested this product extensively, and found that using it saved time, effort and shavings... we found the dirtier the stall, the more you see the advantage over hand-picking. We found we ended up with a cleaner stall..."

Only five minutes is the average cleaning time per stall which is a 65% cleaning time savings for most folks. You should also save as much as 50% on your bedding cost. No more arm or back pain. No more odor and fewer flies. The more stalls you have the faster the machine will pay for itself.

HEALTHIER FOR YOU AND YOUR ANIMALS

New User Instructions:

1. Scrape the bedding from under where you are going to use the machine.
2. Wheel the machine into the stall, place the muck bucket under the end of the machine, plug it in, turn it on.

3. Shovel the manure and bedding onto the shaking screen. The bedding is mixed and drops through the machine onto the stall floor ready for spreading as the manure rolls off the end into the muck bucket.
4. Remove the bucket and machine, and spread the bedding.
5. Do not load the screen before turning on the machine.
6. Do not overload the screen which may result in some bedding falling into the muck bucket.

